

OCS-T Crane Scale

- 3000kg or 5000kg capacity
- Accurate to 1kg (3000kg) / 2kg (5000kg)
- Durable aluminium die cast case
- Clear LED display
- Stainless steel shackle and swivel hook
- Overload alarm
- Tare/Hold/Zero functions
- 1 year warranty



Accurate and durable

Accurate and durable solution for suspension weighing.

Constructed from aluminium, the OCS-T scale is hard-wearing, reliable and built to last. A choice of 3000kg or 5000kg capacities and can be operated from a distance.

Heavy duty construction

The OCS-T is a highly robust and accurate weighing scale. A fixed shackle and swivel hook are constructed from stainless steel to provide the scale with strength and durability.

Fitted with an overload protection alarm, the scale will make an audible sound when nearing maximum capacity.

Large, bright display

A large, bright display which makes the weight reading easy to see from various distances within a range of environments.

Included with every OCS-T scale is an infrared remote control, which means that the scale can be left in a fixed position and the user can safely operate the scale without having to move or dismantle the crane scale.

Capacity:	3000kg/5000kg	Power Supply:	Rechargeable Batteries
Graduations:	1kg (3000kg) / 2kg (5000kg)	Battery Life:	120h of continuous use
Functions:	Zero/Hold/Tare/Overload Alarm	Weight:	13.4kg
Dimensions:	540mm x 255mm x 210mm	Warranty Period:	1 year