

# MARSDEN

## Digi DC-788

Sophisticated Parts Counting Scale



Ideal for inventory control, stock takes and despatch

Hi/lo alarm, Accumulation and second scale input

Water resistant keypad

100 item memory

[www.marsden-weighing.co.uk](http://www.marsden-weighing.co.uk)



## DC-788: Make processes faster, easier and more accurate with an easy to use, flexible parts counting scale

The **Digi DC-788** is ideal for counting parts across warehouse, factory or depot. This easy to use scale has a 100 item memory for quick access to popular items and enhanced software enables easier and more flexible parts counting.

## Robust counting whatever the environment

The Digi DC-788 is a tough counting scale, suitable for demanding environments where regular, high accuracy counting tasks are carried out. Its **durable shell** and **water-resistant keypad** make it perfect for many environments and for many uses. The **bright red LED electronic display** shows the weight reading brightly and clearly.

The **low profile stainless steel top pan** provided can be wiped down to keep it clean and adds a professional finish to this counting scale.

## Choice of capacities and accuracies

The DC-788 has a **choice of capacities and graduations** available to meet your needs. Capacities range from 0.5kg to 50kg and graduations are available from 0.02g to 2g.

The **Tare function** means that any unwanted weight, such as the weight of a bowl, can be removed for a highly accurate counting result.





## Simplify your counting processes

For more streamlined counting processes, set a target count. The **Hi/lo alarm** means the user knows when a target quantity has been reached.

## Key features

- Stainless steel top pan
- Bright red LED display
- Water resistant keypad
- Adjustable levelling feet
- 100 item memory
- Zero
- Tare/Preset Tare
- Hi/lo alarm
- Auto-power off
- RS-232 and external scale port fitted as standard



## Easy access functions

The DC-788 is packed with easy to use functions which make weighing and counting easier. **The 100 item memory** means you can access the weight of the items you count the most instantly, and get straight on with counting batches of those items. **Accumulation** means batches of items can be counted and then the overall total provided.

## Specification

- Capacity: 0.5kg - 50kg
- Graduations: 0.02g - 2g
- Power Supply: Mains
- Dimensions: 350mm x 120mm x 335mm
- Weight of Scale: Approximately 5kg

# DC-788: Key features at-a-glance



# MARSDEN

Tel: 01709 364296 / 0800 169 2775

Fax: 01709 364293

E-mail: [sales@marsdengroup.co.uk](mailto:sales@marsdengroup.co.uk)

[www.marsden-weighing.co.uk](http://www.marsden-weighing.co.uk)

[f](#) MarsdenWeighing

[t](#) @MarsdenWeighing

[You Tube](#) [www.youtube.com/MarsdenWeighing](http://www.youtube.com/MarsdenWeighing)

[P](#) <http://pinterest.com/marsdenweighing>