

MARSDEN

I-100SS-APP Trade Approved Indicator



- 1/3,000 display resolution
- IP65 wipe-down indicator
- Stainless Steel structure
- LCD weight display with backlight
- 40 hours of continuous use
- Trade Approved Indicator

Marsden I-100SS-APP:

IP65 Stainless Steel Indicator

- 1/3,000 display resolution
- IP65 wipe-down indicator
- Stainless Steel structure
- LCD weight display with backlight
- 40 hours of continuous use
- Suitable for dark environments
- Trade Approved
- Wall bracket provided
- 25mm display
- Easy to use functions



Trade Approved

The I-100SS-APP is our entry level, stainless steel trade approved indicator. This means that the scale can be used when money is exchanging hands due to weight.

We have a vast range of trade approved scales within our range and if you would like to find our more about trade approvals, please visit the Marsden Blog or speak to a member of our team today.

Clear and easy to read

The I-100SS-APP combines tough, rugged build quality with easy to use features and a bright, bold weight display making it perfect for use in all environments.

The indicator is primarily designed for easy buy precise check weighing. Therefore, it has a bright and clear 25mm LCD display, which can easily switch between lb and kg readings.

Wipe-down construction

The I-100SS-APP is suitable for application in a wide range of environments due to the IP65 rated housing which means that the scale can be regularly wiped down.

IP65 rating means that the scale is now only completely protected when it comes to dust particles, but the scale can also be wiped down regularly in order to keep hygienic, with no issue being caused to the scale.

Dimensions:	255mm x 100mm x 140mm	Power Supply:	Mains/Rechargeable
IP Rating	IP65	Approvals:	Trade Approved
Functions:	Tare, Zero, Counting	Warranty Period:	1 Year