

# MARSDEN

## I-550 Multifunctional Indicator



- Programmable stainless steel indicator
- Control other devices
- Record weight readings
- Can be used with platforms, floor scales etc
- Bespoke functionality available
- Power saving mode

# Marsden I-550: Multifunctional Indicator

- Programmable stainless steel indicator
- Control other devices
- Record weight readings
- Can be used with platforms, floor scales etc
- Bespoke functionality available
- Power saving mode
- Optional low power solid state relays
- Optional analogue output (4-20ma)
- Optional 1 of 2 relay control
- Optional silo weighing mode



## Automation

The I-550 indicator has up to two low power solid state relays available. This means the scale can automatically switch other devices on or off.

With the scale having the ability to switch off a feed when you hit a target weight, you eliminate human error in adding the correct quantity to your vessel or pallet. This helps to save money and time.

## Send data

The I-550 features from an RS-232 interface means data - including gross, net and tare weight, date and time - can all be sent to a printer.

This data can also be sent automatically to a spreadsheet on a PC or a remote display. Ask us for data transfer functionality information and what can be created for you.

## All standard features

The I-550 has many standard features, including, full-range Zero, Tare, Pre-set Tare and Tare Recall, plus Peak, Freeze and Silo modes as standard.

Special software writes are available on request, to cater the I-550 scale to your requirements. Speak to our sales team today for a full understanding of how the I-550 can help your internal processes.

<b>Dimensions:</b>	165mm x 110mm x 60mm	<b>Power Supply:</b>	Mains
<b>Analogue Outputs:</b>	4-20mA/0-5vdc/0-10vdc	<b>Approvals:</b>	N/A
<b>Functions:</b>	Tare/pre-set tare, Zero, Hold, Optional Accumulation	<b>Warranty Period:</b>	1 Year