

MARSDEN

Jadever JIK Trade Approved Indicator



- 1/6,000 display resolution
- RS-232 interface board
- IP67 splashproof indicator
- Stainless steel structure
- Large backlit display
- 40 hours of continuous use

Jadever JIK:

Check Weighing Indicator

- 1/6,000 display resolution
- Trade Approved indicator
- RS-232 interface board
- IP67 splashproof indicator
- Stainless Steel structure
- Large backlit display
- 40 hours of continuous use
- 4m of loadcell cable
- Connects to printers, PCs, light tower and remote display
- Suitable for automated processes, including liquid filling



Automate weighing

Automating your weighing processes can save you time, money and even improve weighing accuracy. An in-built hi/lo alarm shows if you are on, near, or above target.

The JIK's optional relay board means weighing, filling (including liquid filling) and loading can be further automated, by integrating into existing systems. Speak to us today for more information..

Data transfer

The RS-232 interface means data - including gross, net and tare weight, date and time - can all be sent to a printer or to an internal system on a PC.

Simply connect the Marsden U-Key and all information from the weighing scale will feed seamlessly into your PC so easy storage and monitoring. Enquire today for more information.

Splashproof

The JIK is suitable for application in a wide range of environments due to the IP67 rated housing which means that the scale can be regularly washed down.

IP67 rating means that the scale is now only completely protected when it comes to dust particles, but the scale can also be washed down regularly in order to keep hygienic, with no issue being caused to the scale.

Dimensions: 290mm x 100mm x 190mm

IP Rating IP67

Functions: Tare/Pre-set Tare, Zero, and Counting

Power Supply: Mains/Rechargeable

Approvals: Trade Approved

Warranty Period: 1 Year