

Stainless Steel Lift Up Platform Scale



- Stainless steel lift up platform scale
- Hydraulic assist lifting top plate
- IP68 rated water resistant base

- · Ideal for use in food manufacturing facilities
- Suitable for harsh and wet environments
- Available with a wide range of indicators

Marsden LP Platform: Stainless Steel Lift Up Platform Scale

- · Hydraulic assist platform scale with lifting top plate
- IP68 rated making this device suitable for regular cleaning
- Supplied with 1 year warranty as standard
- Constructed from 304 food grade steel
- Premium quality manufacturing for long life

- Available with a wide range of indicators depending on function and environment
- Adjustable levelling feet
- Capacities up to 3000kg and accurate from 0.2kg
- Various dimensions available



Hydraulic lift top plate

The LP Platform has a hydraulic lifting top plate. With the help f hydraulics, the platform can be opened with ease, enabling the user to clean the scale with ease.

The LP Platform benefits from premium quality manufacturing. It is strong, durable and perfect for heavy use. The device also features from a supportive strut for additional safety.

IP68 rated platform scale

This is an IP68-certified platform scale that can be used in harsh environments. That means that this device can be hosed down on a regularly.

This platform is IP68-rated. The IP rating refers to protection against water and dust. The first digit (e.g. '6') refers to protection to dust and the second (e.g. '8') is protection against water and other liquids.

Various indicators available

This weighing platform can be paired with a wide range of indicators to create a truly bespoke and fit for purpose weighing scale, ideal for all applications.

We pride ourselves on having a wide range of indicators available to ensure that can suit the requirements of our customers. Speak to us today to learn more or visit the Marsden website.

Capacity:	600kg to 3000kg	Power Supply:	Dependant on Indicator
Graduations:	0.2kg to 1kg	Battery Life:	Dependant on Indicator
Functions:	Dependant on Indicator	Approvals:	Available Approved and Non-Approved
Dimensions:	Various dimensons availale	Warranty Period:	1 Year