

MARSDEN

OCS-S1 Lightweight Crane Scale



- Capacity: 100kg / 300kg / 500kg / 1000kg
- Graduations: 0.05kg / 0.1kg / 0.2kg / 0.5kg
- Aluminium die cast case
- Clear LED display
- Stainless steel shackle and hook
- 1 year Marsden warranty

Marsden OCS-S1:

Lightweight Hanging Crane Scale

- Capacity: 100kg / 300kg / 500kg / 1000kg
- Graduations: 0.05kg / 0.1kg / 0.2kg / 0.5kg
- Aluminium die cast case
- Clear LED display
- Stainless steel shackle and hook
- Zero mode
- Tare function
- Hold mode
- Overload alarm
- 1 year Marsden warranty



What is the OCS-S1?

The OCS-S1 is a lightweight, high accuracy hanging/crane scale available in a range of capacities to suit different industries and needs.

The scale is ultra-lightweight and battery powered. A bright LED display means it is clearly visible from long distances and it can be operated via an infrared remote control, ideal for warehouses.

Heavy duty construction

The OCS-S1 is an easy to use crane scale, which is highly robust and accurate. A fixed shackle and hook are constructed from stainless steel to provide strength.

To maintain the scale's accuracy and inner mechanisms the OCS-S1 is fitted with an overload protection alarm, which will sound when the scale is near the maximum amount of load.

Large, bright display

The OCS-S1 has a large, bright red LED display which makes the weight reading easy to see from various distances in different environments.

As standard, an infrared remote is sold with the OCS-S1, which means that the scale can be left in one fixed position and the user can safely operate the scale without having to move or dismantle the crane scale.

Functions:	Zero, Tare, Hold, Overload Alarm	Power Supply:	Rechargeable Batteries
Warranty Period:	1 Year	Battery Life:	120 hours of continuous use
Dimensions:	60mm x 145mm x 275mm	Optional Extras:	N/A