

# MARSDEN

## OCS-Z High Capacity Crane Scale



- Capacity: 10,000kg / 20,000kg
- Graduations: 5kg / 10kg
- Aluminium die cast case
- Large, clear LED display
- Stainless steel shackle and hook
- 1 year Marsden warranty

# Marsden OCS-Z:

## High Capacity Crane Scale

- Capacity: 10,000kg / 20,000kg
- Graduations: 5kg / 10kg
- Aluminium die cast case
- Large, clear LED display
- Stainless steel shackle and hook
- Zero mode
- Tare function
- Hold mode
- Overload alarm
- 1 year Marsden warranty



### What is the OCS-Z?

If you are short on space in your factory or warehouse, or need to weigh awkwardly shaped goods, choose the OCS-Z Crane Scale.

This is Marsden's highest capacity crane scale, suitable for weighing goods up to 20,000kg. This crane scale is ideal for weighing goods to avoid overloading of cranes and vehicles.

### Heavy duty construction

The OCS-Z is a highly robust and accurate weighing scale. A fixed shackle and hook are constructed from stainless steel to provide the scale with strength and durability.

To help maintain the scales accuracy and inner mechanisms the OCS-Z is fitted with an overload protection alarm, which will sound when the scale is near maximum capacity.

### Large, bright display

The OCS-Z has a large, bright red LED display which makes the weight reading easy to see from various distances in different environments.

As standard, an infrared remote is sold with the OCS-Z, which means that the scale can be left in one fixed position and the user can safely operate the scale without having to move or dismantle the crane scale.

<b>Functions:</b>	Zero, Tare, Hold, Overload Alarm	<b>Power Supply:</b>	Mains/Rechargeable
<b>Warranty Period:</b>	1 Year	<b>Batteries:</b>	6V/ah Rechargeable Battery
<b>Optional Extras:</b>	N/A	<b>Battery Life:</b>	120 hours of continuous use