# MARSDEN

## PT-400 Pallet Truck Scale



- Waterproof IP67-Rated Scale
- Bright red LED display
- Stainless steel construction

- · Dimensions to fit euro pallet
- Easy to use indicator
- 70 hours continuous use

## Marsden PT-400:

## Waterproof Pallet Truck Scale

- Waterproof IP67-rated scale
- IP68 loadcells
- Bright red LED display visible in most conditions
- Stainless steel construction
- Dimensions to fit euro pallet

- Easy to use indicator
- 70 hours continuous use
- Zero, Tare and Pre-Set Tare functions for easier weighing
- Easy-rolling cast wheels
- Adjustable height for forks



#### Waterproof

The PT-400 is an IP68 rated scale. This means the PT-400 can withstand use in almost any environment that's damp, wet, and humid.

It also means the scale can be washed down regularly to keep it clean and hygienic. Making it the ideal weighing solution for use in factories, warehouses, breweries and food manufacturing.

### Long-life battery

In addition to the mains adaptor, the PT-400 also has an internal rechargeable battery, which lasts up to 40 hours, meaning it can last all week long.

Due to the programmeable auto power-off function, the scale will turn off when it has been left idle for a minimum of 10 minutes, to help preserve battery life and ensure your scale is always ready.

### Easy to use functions

The PT-400 is packed with easy to use features making weighing for the user even easier, within a vast number of environments.

Tare allows you to remove the weight of the pallet from the reading. Hold will stabilise the weight reading. A simple counting function allows you to add up items on a pallet quickly and easily.

Capacity:	2000kg	Power Supply:	7.2V battery pack
Graduations:	500g	Battery Life:	40 hours of continuous use
Functions:	Zero, Tare, Pre-Set Tare, Portable	Approvals:	Non-Approved
Dimensions:	1570mm x 545mm x 730mm	Optional Extras:	N/A
Weight of Scale:	136kg	Warranty Period:	1 Year