

MARSDEN

PT-450 Pallet Truck Scale



- Waterproof IP68-Rated Scale
- 32mm high red LED display
- Stainless steel construction
- Dimensions to fit euro pallet
- Weighs in kg or lb
- 40 hours continuous use

Marsden PT-450:

Waterproof Pallet Truck Scale

- Waterproof IP68-Rated Scale
- Multi-functional indicator - unit switchable
- Auto power off saves battery life
- Bright LED display visible in most conditions
- Adjustable fork height
- Hold, Zero, Gross and Tare functions for easier weighing
- 40 hours of continuous use
- Dimensions to fit euro pallet
- Made to order
- Covered by 1 year warranty



Waterproof

The PT-450 is an IP68 rated scale. This is the highest waterproof rating Marsden supply, and it means the PT-450 is suitable for almost any environment.

It also means the scale can be washed down regularly to keep it clean and hygienic. Making this pallet truck scale suitable for use in warehouses, factories, breweries and food production industries.

Long-life battery

In addition to the mains adaptor, the PT-450 also has an internal rechargeable battery, which lasts up to 40 hours, meaning it can last all week long.

Due to the programmable auto power-off function, the scale will turn off when it has been left idle for a minimum of 10 minutes, to help preserve battery life and ensure your scale is always ready.

Easy to use functions

The PT-450 is packed with easy to use features making weighing for the user even easier, within a vast number of environments.

Tare allows you to remove the weight of the pallet from the reading. Hold will stabilise the weight reading. A simple counting function allows you to add up items on a pallet quickly and easily.

Capacity:	2000kg	Power Supply:	Mains/Rechargeable
Graduations:	500g	Battery Life:	40 hours of continuous use
Functions:	Zero, Tare, Hold, Portable	Approvals:	Non-Approved
Dimensions:	1570mm x 545mm x 800mm	Optional Extras:	N/A
Weight of Scale:	136kg	Warranty Period:	1 Year