

# MARSDEN

## PT-500 Pallet Truck Scale



- Heavy duty pallet truck scale
- 32mm high red LED display
- Four load cells
- Dimensions to fit euro pallet
- Weighs in kg or lb
- 40 hours continuous use

# Marsden PT-500:

## Pallet Truck Scale

- Heavy duty, Mild steel construction
- 6v 4.5A/hr battery
- Multi-functional indicator - unit switchable
- Auto power off saves battery life
- Bright red LED display visible in most conditions
- Low profile forks
- Zero, Tare and Hold functions for easier weighing
- 40 hours of continuous use
- Durable rubber handle for secure grip
- Dimensions to fit euro pallet



### Easy, portable weighing

The PT-500 is built for demanding day-to-day weighing jobs, ideal for use in warehouses, factories and other high heavy industry environments.

The 32mm high red LED electronic display shows the weight reading clearly, even from a distance or in poorly-lit environments. The forks have been designed to weigh standard euro palettes.

### Long-life battery

In addition to the mains adaptor, the PT-500 also has an internal rechargeable battery, which lasts up to 40 hours, meaning it can last all week long.

Due to the programmeable auto power-off function, the scale will turn off when it has been left idle for a minimum of 10 minutes, to help preserve battery life and ensure your scale is always ready.

### Easy to use functions

The PT-500 is packed with easy to use features making weighing for the user even easier, within a vast number of environments.

Tare allows you to remove the weight of the pallet from the reading. Hold will stabilise the weight reading. A simple counting function allows you to add up items on a pallet quickly and easily.

<b>Capacity:</b>	2000kg	<b>Power Supply:</b>	Mains/Rechargeable
<b>Graduations:</b>	500g	<b>Battery Life:</b>	40 hours of continuous use
<b>Functions:</b>	Zero, Tare, Hold	<b>Approvals:</b>	No
<b>Dimensions:</b>	1570mm x 545mm x 730mm	<b>Optional Extras:</b>	N/A
<b>Weight of Scale:</b>	125kg	<b>Warranty Period:</b>	1 Year