

PT-700 Trade Approved Pallet Scale with Printer



- EC Trade Approved pallet truck scale
- 32mm bright red LED display
- Dimensions to fit euro pallet

- In-built printer
- 40 hours of continuous use
- 4m of loadcell cable included

## Marsden PT-600: Pallet Truck Scale with Printer

- EC Trade Approved pallet truck scale
- Heavy duty, mild steel construction
- Powered by 4x C-sized batteries
- Multi-functional indicator unit switchable
- Auto power off saves battery life

- Built-in printer
- Bright red LED display visible in most conditions
- Low profile forks
- Zero, Tare and Hold functions for easier weighing
- 40 hours of continuous use



## Keep track of every reading

The built-in printer on the PT-700 allows you to print gross weight, net weight and tare weight, as well as count information when the scale is in counting mode.

Select the accumulation function and you can print the total weight of a number of pallets, too - helping you to avoid overloading of lorries and giving you the ability to obtain accurate weights.

## Trade Approved

Regardless of whether you call it Class III Approved or Trade Approved, the PT-400 weighing scale is approved to the NAWI Directive.

This means that the PT-700 is suitable for applications where a Trade Approved weighing scale is required. For example, if you are charging via weight, your device must be Trade Approved

## Easy to use functions

The PT-700 is packed with easy to use features making weighing even easier for all factory and warehouse staff when manoeuvring goods.

Tare will remove the weight of the pallet from the reading. Hold will stabilise the weight reading. A simple counting function allows you to add up items on a pallet quickly and easily.

Capacity:	2000kg	Power Supply:	Mains/Rechargeable
Graduations:	1kg	Battery Life:	40 hours of continuous use
Functions:	Zero, Tare, Hold	Approvals:	EC Trade Approved
Dimensions:	1570mm x 545mm x 730mm	Optional Extras:	Print Roll
Weight of Scale:	125kg	Warranty Period:	1 Year